



# ROMA<sup>®</sup> CHECK VALVES

## 104 ROMA<sup>®</sup> check valve

### DIAGRAM OF THE MINIMUM PRESSURE NEEDED TO GET THE VALVES OPENING

The opening of the valve is given by the different pressure between the two sides of the seat.

