



# BLOCK<sup>®</sup> CHECK AND FOOT VALVES

## 106 Block<sup>®</sup> foot valve

### DIAGRAM OF THE MINIMUM PRESSURE NEEDED TO GET THE VALVES OPENING

The opening of the valve is given by the different pressure between the two sides of the seat.

