



YORK[®] CHECK AND FOOT VALVES

108 YORK[®] foot valve

DIAGRAM OF THE MINIMUM PRESSURE NEEDED TO GET THE VALVES OPENING

The opening of the valve is given by the different pressure between the two sides of the seat.

